



5 Minute Safety Meeting

for the foreign workers

Placing of Concrete(II)

A. Concrete Placing by Handcart

- Be sure to use the pathway for handcart only.
- When pouring concrete from handcart, maintain the speed to prevent overturn or fall.
- Use the double insulated wires for vibrator and make sure of grounding.
- Upon completion of work, remove concrete from handcart, shovel, conveying vehicle, etc. and keep them at the designated place.

B. Concrete Placing by Pump Car

- Pump handle should be operated by its operator only.
- Make sure to fix the joint of supply line firmly, and do not install the pipes to be adjacent to the pathway and working area.
- When taking out the pipe, release the pressure slowly by taking out the pipe bit by bit for concrete to be discharged.
- For air cleaning, be sure to remove the flexible hose.
- Notify the hazard of entrapment at the bent part of chute, and control it.

콘크리트 타설작업(II)

가. 손수레에 의한 타설작업

- 손수레의 통로를 명확하게 구분하여 사용한다.
- 손수레로부터 콘크리트를 부을 때에는 전락이나 추락을 방지할 수 있는 속도를 유지한다.
- 진동기의 전선은 캡타이어를 사용하고 접지를 확실히 한다.
- 손수레, 삽, 운반기구 등은 작업종료시 콘크리트를 제거하고 지정된 장소에 보관한다.

나. 펌프카에 의한 타설작업

- 펌프 조작핸들을 운전수 이외의 작업원이 조작하지 않는다.
- 송급관의 이음은 확실히 연결하고, 배관이 통로 및 작업장소에 근접되게 설치하지 않는다.
- 배관을 빼어낼 때 조금씩 빼어 콘크리트를 나오게 하여 압력을 서서히 개방시켜야 한다.
- 공기 세정시에는 반드시 후렉시블 호스를 떼어내야 한다.
- 슈트 굴절부분에 대한 협착 위험을 주지시키고 이를 통제하여야 한다. 