[II-1]

X-ray photoelectron spectroscopy studies of ferroelectric PZT thin films prepared by metalorganic chemical vapor deposition method

<u>Jeong Woo Choo</u>*, Young Kwan Kim*, Byoung Chung Sohn*, Chanyong Hwang**, Young Soo Yoon***, Jeon Kook Lee***, and Tae Song Kim***

Recently, ferroelectric thin films have attracted great interest because of its applications for ferroelectric random-access memories (FERAMs) and dynamic random-access memories (DRAM)s). In order to obtain ferrolectric thin films, various thin film techniques, such as the sputtering, evaporation, chemical vapor deposition, and sol-gel methods, have been reported.

Thin films of Lead Zirconate Titanate, Pb(Zr, Ti)O₃ (PZT), were grown on Pt/SiO₂/Si(100) by metalorganic chemical vapor deposition (MOCVD), using Pb(tmhd)₂, Ti(OC₃H₇)₄, Zr(tmhd)₄ and O₂. These films were analyzed with X-ray photoelectron spectroscopy (XPS) for determining the chemical composition and chemical bonding characteristics. It was found that the chemical compositions and chemical bondings of ions in the near surface are different from those in the bulk region of the films. The oxidation state of titanium ions in the bulk region is reduced in comparison to that of titanium ions in the surface region of the films and lead enrichment in the near surface region was also observed. Lead ion in the surface region exists mainly in the form of PbO_{ads} (oxygen-chemisorbed lead), but lead ion in the bulk region exists in the form of mixture of PbO and PbTiO₃. More details on the chemical bonding characteristics of the ions in PZT thin films will be discussed.

References

- 1. Z. Qian, D. Xiao, J. Zhu, Z. Li, and C. Zuo, J. Appl. Phys. 74 (1), 1 July 1993.
- 2. M. Shimizu, T. Katayama, M. Sugiyama, and T. Shiosaki, Jpn. J. Appl. Phys. Vol. 32 Pt. 1, No. 9B, 1993.

Department of Chemical Engineering, Hong-Ik University, Seoul, KOREA

^{**}Korea Research Institute of Standards and Science, Taejon, KOREA

^{**&}quot;Korea Institute of Science and Technology, Seoul, KOREA