Latest Sizing Solution for Fine Paper

백상지용 최신 사이즈제


Mr. David Li

CIBA APAC



제33회 펄프ㆍ종이기술 국제세미나









Latest Sizing Solution for Fine Paper Seoul

David Li – Marketing Manager-Sizing, APAC May 23rd, 2008

Ciba

Water & Paper Treatment

Sizing paper with chemical additives

Internal Addition

To Reduce Fiber Wettability

Rosin Sizes - Dispersed Rosin Sizes - Rosin Soap Sizes

Cellulose Reactive Sizes - AKD, ASA Wax Emulsions

Treatment

Surface

To Reduce Fiber Wettability

Cellulose Reactive Sizes Wax Emulsions

To Reduce Pore Radius

CMC SMA Copolymers Starches SAE Emulsion

Sizing, brings about a reduction in the capillarity and hydrophilicity of the cellulose, thus, make it possible to control the penetration of fluid.

Ciba

Drivers of Fine Paper

Apart from **cost saving** and **machine runnability**, some paper makers are also doing the follows to differentiate their paper products from others':

- MAKING HIGH ASH CONTENT PAPER
 - Surface area, alkalinity/hydrolysis
- HIGH WHITENESS PAPER
- PCD, Retention performance

WHAT SHALL WE DO FOR PAPER MAKES AS A SUPPLIER?



Water & Paper Treatment

Market Trend of Sizing

Acid



Neutral:

Corrosion, Alum, Filler selection;
 (AKD, ASA, Cationic rosin dispersion)

Internal Surface:

Cost reduction, Runnability Improvement
 (Promoted AKD, SAE, Liquid AKD based)




From Internal to surface - Sizing contribution


Surface size: 10-50%

Surface size: 25-90%





Traditional Size



Innovative Size



Water & Paper Treatment

Advantages of surface sizing

- Strength properties picking resistance, reduction of linting;
- 100% yield of sizing agent no retention problem;
- Decrease of sizing costs as the basis weight increases;
- Reduce the wet end deposit issue & improve machine runnability less wet end size;
- Enable higher ash content loading & High whiteness paper especially for fine paper;
- Improve the two-sideness in terms of hydrophobicity;
- A wide range of polymer sizing agents flexibility;
- ■Improve the printability
- Effect/performance

Ciba



Surface Size Comparison

Traditional-SAE

Innovative- Reactive surface size

$$R_1 - CH_2 = C - CH_2 - R_2$$
 $O - C$
O


Dipole-dipole interaction;
Good film-forming, less hydrophobic


Covalent bonding; More hydrophobic

Ciba


Water & Paper Treatmen


COBB - Raiprint 600 vs. SAE





Ciba





Strengths & Weaknesses against traditional HSS


Product	Ciba® RAIPRINT® 600	SAE or SMA Surface Sizes
Strengths	 High hydrophobicity Cost/performance Low foaming	 Good film forming Improves toner adhesion Reduces ketone migration Well established
Weaknesses	 Toner adhesion or converting issues not yet faced Less film forming No ketone barrier 	 Lower hydrophobicity Foaming (especially SMA) Low solids (SMA) Cost/performance



Water & Paper Treatment

Océ Standard Copy Press





- In a conventional copier, the toner is transferred from a photoconductive drum to the paper by strong magnetic forces induced by high voltage.
- In Océ copiers, the 'drum' is a photoconductive belt.
- Transfer and fusing of toner onto paper occur in one step.



Problems Caused By AKD

Standard Copiers

- Ketones can be transferred from paper to the Fuser Belt.
- Fuser in direct contact with the Photoconductor so ketones can be crystallised on to the (low temperature) Photoconductor.
- Areas with ketones can be charged but not discharged, which gives a shadowy background.
- Melting point of AKD and ketones is the critical factor.



Water & Paper Treatment

Comments By Océ

Standard Copiers

- Worst paper is that surface-sized with conventional AKD.
- Conventional AKD in the surface is NOT allowed.
- Fillers may have a 'binding' action on ketones (adsorption?)
- · Fatty acids decompose the Fuser Belt.
- · Stearic acid crystallises rapidly.
- If <1.2mg/g ketones on Fuser Belt after 20 000 copies, a life-time of several '00 000 copies is expected.



Ciba













Ciba® RAIPRINT® 600

Innovative surface size Based on liquid wax Reactive surface size

Patent technology (Case number 23120)



Water & Paper Treatment

Technical features

General

- Ciba® RAIPRINT® 600 is a new, cellulose reactive hydrophobic surface sizing agent applied as an additive in the size press
- The product is designed to give a high degree of sizing and is primarily designed for neutral/alkaline paper making conditions
- Ciba® RAIPRINT® 600 is designed for use in all grades of uncoated fine paper (copy, bond, offset, envelope)

• Product information

State:

white dispersion

Viscosity:

<100 cP

Dry solids:

20% +/- 0,5%

pH:

3,5-4,5

Charge:

Amphoteric



Value propositions

- 1. Reduce total sizing costs Improve total size cost balance internal/surface
- 2. Reduce wet end size usage Cost, wet end flexibility, reduce deposits, bring sizing to surface
- 3. Improve printability Increase hydrophobicity, improve holdout
- 4. Help facilitate higher filler loadings *More efficient sizing with higher surface* area base sheet
- 5. Improve machine cleanliness/runnability Less wet end ASA less hydrolyzate, fewer deposits
- 6. Improve the two-sideness regarding hydrophobicity



Water & Paper Treatment

Potential users

- Uncoated or coated Fine Paper
- Using ASA/AKD as the internal size;
- Have deposit/runnability issue;
- Using SAE/SMA product as the surface size;
- Willing to reduce the overall sizing cost;
- Ash content >20% or may wish to increase it further;
- Wants to make high whiteness grade



Case Study 1 - Raiprint 600

Fine Paper Machine AKD as Internal Size



Water & Paper Treatment

Trial Background

- WFU; Copy and Offset
- Production 285.000 t/a, 36-37 t/h, speed 1200 m/min
- Current Sizing Concept
 - AKD as an internal size
 - 0,3 % (20% AKD) for Copy Grades
 - 0,6 % (20% AKD) for Offset
 - B*** 400DS as a hydrophobic surface size (Styrene Acrylate)
 - 0,6 % (as received) for Copy Grades
- Aim of the trail was to reduce the sizing costs
 - By replacing B*** 400DS
 - By decreasing the dosage of internal size



Raiprint 600 Trial

- Raiprint 600 was added into the surface size service tank.
- 0,6 % of SA-type HSS was replaced by 0,25 % of Raiprint 600 at the beginning.
- Dosage of Raiprint 600 was then reduced from 0,25 % to 0,17 % and 0,15 %.
- Dosage of internal size (AKD) was constant at 0,3 % (as received) during the trial.



Water & Paper Treatment

Results

- No runnability problems
 - No foaming
 - Film on size press was normal
- Friction of paper was on same level or even higher than Raiprint 600
- Sizing was improved with Raiprint 600 compared to situation before the trial
- No changes in toner adhesion

According to sizing values it is possible to replace 0,6 % competitors SA-type HSS with about 0,2 % of Raiprint 600.

The hydrophobic surface sizing (HSS) cost was reduced at least by 50 %



Ciba Raiprint 600

Case Study 2 - Raiprint 600

Fine Paper Machine ASA as Internal Size



Water & Paper Treatment

Case study 2

MACHINE DETAILS

Locations: CHINA

Machine Type - Gap Former

Machine Speed - 1650 m/min (65tph)

Grade - Uncoated Fine Paper (Copy, Offset)

Furnish - Acacia and Eucalypt

RETENTION & DRAINAGE AID SYSTEM

Percol 182 - 0.210 kg/t

 $\textbf{Telioform} \ M100 - 0.200 \ kg/t$

Telioform B1030 - 2.30 kg/t

FPAR - 35-40%WW Solids Set Point - 0.35%



Trial background and aims

Sizing system before the trial:

Wet end Size: 1.0 kg/t ASA

Surface size: 2.5 kg/t SAE

Cobb 60 s Target: 24 for copy paper

Ash content: 26% GCC

Aim: To reduce the ASA dosage, and overall sizing cost; improve the two-sideness.

Ciba

Water & Paper Treatmen

Results and summary

- Raiprint 600 was added into the suction side of pump for surface starch service tank.
- With the same Cobb value, internal ASA dosage was reduced from 1.0 kg/t to 0.75 kg/t, while surface size dosage was decreased from 2.5 kg/t to 1.3 kg/t paper.
- 2-sideness was also improved according to the Cobb of top/btm.
- Another benefit is that Cobb is more consistent/controllable when high whiteness grade is made.



Water & Paper Treatmen

Ciba

Some Raiprint 600 results worldwide

Grade	Pre-trial	Results	Pre-trial	Results
	Int.size	Int.size	HSS	Raiprint 600
Envelope	ASA 1,2 kg/t	ASA 0,7 kg/t	SA, 2,3 kg/t	1,7 kg/t
80-100gsm Porosity 500-600 ml/min		- 40%		- 26%
Pre-print	ASA 1,2 kg/t	ASA 0,85 kg/t	SA, 2,3 kg/t	2,1 kg/t
80 gsm Porosity 800-900 ml/min		- 30%		- 10%
Office	ASA 0,8 kg/t	ASA 0,65 kg/t	SA, 2,0 kg/t	1,0-1,4 kg/t
60-80 gsm Porosity 600-700 ml/min		- 20%		- 30 - 50%
Office	AKD 0,6 kg/t	AKD 0,6 kg/t	SA, 6,0 kg/t	1,5 -2,0 kg/t
80 gsm Porosity 800-900 ml/min				- 70% -75%
Office	ASA 1,7 kg/t	ASA 0,9 kg/t	Only Starch	1,5 kg/t
80 gsm Porosity 700-800 ml/min		- 45%		

____ Ciba

Water & Paper Treatment

Thank you!

Q&A

